Instruction Manual



OIL-FREE WALL MOUNTING KIT & HANGING-DOWN KIT

for AKIMist® Dry Fog Humidifying System

Thank you for purchasing AKIMist Humidifier with Wall Mounting or Hanging-down Kit. To properly use the installation kit, please read this instruction manual.

■ Check the contents of the box.

Contents:

AKIMist with connection kit, AKIMist Instruction Manual, and this manual

> Bolts and hanging fixture are not included and need to be supplied by customer

■ Parts Description

For order of spare parts, use specific description and code number below.

Section	Part No.	Description	Material*	Code No.
Air	1	Valve (Red)	S304	#289481
Line	2	Nipple	S304	#14634
	3	Pressure Regulator (with pressure gauge)	POM, aluminum	#265941
	4	Coupler (Socket)		#193606
	5	Coupler (Plug)		#12234
	7	Fixed Socket & Nut Set	S303	#14038
		(Socket)		(#109007)
		(Nut)		(#109008)
Water	6	Valve (Blue)	S304	#289482
Line	7	Fixed Socket & Nut Set	S303	#14038
		(Socket)		(#109007)
		(Nut)		(#109008)
	8	Tube Fitting (Elbow)		#130693
	9	Tube	Nylon	#18582
	10	Tube Fitting		#130694
	11	Liquid Coupler (Socket)	Polyacetal	#157467
	12	Liquid Coupler (Plug)	S303	#216627
Plate	13	Plate for Wall Mounting	S304	#186169
	14	Plate for Hanging-down	S304	#186170

^{*}Materials S303/S304/S316's "S" means stainless steel in this manual.


14(13) 11 12

> The sketch above shows HANGING-DOWN KIT. Please note that shape of plate (#13) for WALL MOUNTING KIT is different from the above.


Note: Parts No.5 and No.12 are provided in the AKIMist humidifier, not in the kit.

How to Install

■Wall Mounting Kit



■Hanging-down Kit



Joint part

Cover part

The part numbers mentioned in the assembly instructions correspond to the parts listed on the previous page.

 Connect the liquid coupler socket (Part #11) to the liquid coupler plug (#12) of AKIMist humidifier.

Push the coupler into the black cover part until it clicks into place. The joint part indicated in the diagram will be hidden under the black cover.

- (2) Secure the plate on the wall or ceiling with bolts or a hanging fixture.
- (3) Connect air and water tubes to valves (#1 and #6) respectively. Rc 1/4" threaded connection for both air and water. (Recommended torque: 15 N-m)
- (4) Open valves (#1 and #6) and set the air pressure with pressure regulator (#3).

For installation and operation of AKIMist, refer to the enclosed Instruction Manual for AKIMist Dry Fog Humidifier.

⚠ Caution

- Connect the air pipe and water pipe correctly.
- When wall-mounted, do not aim the spray nozzles towards the wall.
- Be careful not to drop anything during installation at high places.
- For inquiry/order, use the specific part name and code number on the previous page.

H. IKEUCHI & CO., LTD.

Daiichi Kyogyo Bldg., 1-15-15, Awaza, Nishi-ku, Osaka 550-0011 JAPAN

Fax: +81-6-6538-4022

Email: overseas@kirinoikeuchi.co.jp https://www.kirinoikeuchi.co.jp/eng/